



MOTO-MATE Suzuki GSX-S1000GX Raised Navigation Mount Installation

Please Note:

Steps

- 1) Remove the screen and place it somewhere safe where it won't get scratched
- 2) Mount your nav cradle / phone mount to the head of the nav' mount

TomTom / Garmin / Phone?

If you are using a Garmin nav device it will use 4mm threaded fasteners, in this case please insert the aluminum spacers into the holes to take up the clearance. TomTom, Quadlock and other systems that use 5mm threaded fasteners will not require these spacers.

- 3) Place the two stepped spacers on the upper screen mounting rubbers, I use a dab of grease to hold them in place
- 4) Place the nav' mount inside the screen and locate both with one of the longer screws and large washers from the kit
 - a. Once the screen is located mount the other screws but do not tighten until all 4 screws are in place and you have checked the alignment of the nav mount.
 - b. When all is good pinch up the 4 screws **NOTE: If using an aftermarket screen that does not have a flat platform for the screws to tighten against take care not to overtighten and crack the screen.**
- 5) Place nav / phone into the holder and set the desired position and tighten the 4 screws on the knuckle
- 6) Connect your power source
- 7) Replace the screen.

There is also a video on our YouTube channel covering the installation of this mount: <https://youtu.be/oT8v596yOXg>

PLEASE NOTE:

When fitting your nav, please support the nav mount from behind to resist the pressure of mounting the nav' unit