



BMW R1300RS Nav Mount

Installation Instructions

Please note:

The wiring used for the BMW Connected ride device cradle will NOT reach the position of the raised navigation mount. The connector used on the cradle is proprietary to BMW and not available to make an extension lead.

Therefore if you wish to use the BMW Connected Ride device then you do not need the Moto-Mate mount.

If however, you wish to use a traditional navigation device or your smartphone or a smartphone mirroring device and your bike is equipped with the BMW cradle, remove this cradle and seal off the connector and tie it up somewhere out of the way and proceed as follows:

- 1) Remove the screen of your bike and place it somewhere safe where it won't get scratched
- 2) Lift the screen frame to the upper position
- 3) Remove the lower of the two trim panels under the screen.
 - a. There are two "spring clips" at the top and one in the middle at the bottom



- 4) Remove the two screws from the bottom of the upper trim panel



i.

Take care not to drop the screws in the bike

- 5) Release the two spring clips at the top of the panel and remove the panel out through the top
- 6) Remove the two screws behind the tft



- 7) Fit the nav mount over these two screws and secure using the longer screws and washers in the kit
- 8) Replace the upper trim panel and fasten the screws
- 9) Replace the lower trim panel into the three spring clips
- 10) Fit the mounting bracket for your device and use the aluminium top hat bush if your unit uses 4mm screws
- 11) Replace the screen
- 12) Go for a ride and enjoy the new safer position of your nav.

There is a video on our YouTube channel covering the installation process or here is the link: <https://youtu.be/vAU-9kNugho>