



MOTO-MATE Yamaha Tracer 9GT & GT+ Raised Navigation Mount Installation

Steps

- 1) Remove the screen and place it somewhere safe where it won't get scratched
- 2) Remove the bolt behind the tft and mounts the hole in the bottom of the base mount over the raised bush and use the longer M6 bolt in the kit to secure it. **Please Note:** the base mount has a cut out section to allow the block to sit on the top of the frame and the cut goes over the edge of the trim panel preventing rotation.



- 3) Mount your nav cradle / phone mount to the head of the nav' mount

TomTom / Garmin / Phone?

If you are using a Garmin nav device it will use 4mm threaded fasteners, in this case please insert the aluminum spacers into the holes from the back of the nav mount plate to take up the clearance.
TomTom, Quadlock and other systems that use 5mm threaded fasteners will not require these spacers.

- a. Once the device is located mount the other screws but do not tighten until all 4 screws are in place and you have checked the alignment of the device.
 - b. When all is good pinch up the 4 screws
- 4) Place nav / phone into the holder and set the desired height and reach position and tighten the 4 screws on each end of the arms to lock it all in place
 - 5) Connect your power source
 - 6) Replace the screen.

PLEASE NOTE:

When fitting your nav, please support the nav mount from behind to resist the pressure of mounting the nav' unit