

BMW F900XR and F850GS Mk III Nav Mount

Installation Instructions

- 1) Remove the screen of your bike and place it somewhere safe where it won't get scratched
- 2) Raise screen to access the trim panel fixings
- 3) Remove the two plugs that hold the trim panel in place



- 4) Remove the four T30 Torx screws that hold the screen frame in place



- 5) Place nav mount in position over the screen adjusting frame and use the longer M6 x 40 allen bolts in the kit to secure the mount and screen frame back in place

PLEASE NOTE

This is a very snug fit and will require a bit of a wiggle and press to seat it firmly in its proper position

- 6) Fit the revised trim panel using the M4 x 8 Allen screws and washers to the nav mount
- 7) Remove the BMW Navigator cradle from it's mounting bracket and remove the top rubber band that holds the nav wire to the brake line and switchgear wire
- 8) Use the original screws to fit the Navigator cradle into the mount and route the wire behind the tft

- a. Adjust the Navigator cradle to the same angle as the tft
- 9) Replace the screen
- 10) Replace the rubber band around the brake line and switchgear wires
- 11) Remove the original navigator mounting bracket and replace the BMW handlebar bolts with the M8 x 30 mm allen bolts provided
- 12) Go for a ride and enjoy the new safer position of your nav.

Please Note

If you are using the BMW Connected Ride Navigator device (NOT The Connected Ride phone cradle) you may wish to move the cradle to the left. We have an adaptor for this which can be found under the BMW navigation mounts on moto-mate.com